

Overview

Parts are first created in Inventree where they are assigned an IPN. Then they can be created in fusion/solidworks/kicad with the correct IPN. Parts should be named in all caps. The part naming format is <IPN | Name> (example: TRT-0000145/A | EXAMPLE PART)

Revision #3

Created 2026-06-26 21:28:09 UTC by Admin

Updated 2026-06-26 21:43:55 UTC by Admin