

Overview

Parts are first created in Inventree where they are assigned an IPN. Then they can be created in fusion/solidworks/kicad with the correct IPN. Parts should be named in all caps. The part naming format is <IPN | Name> (example: 27_000123_A | EXAMPLE PART)

This needs visuals and to be better in general

Revision #5

Created 2026-06-26 21:28:09 UTC by Admin

Updated 2026-08-16 02:04:23 UTC by Cooper Brown